

Keyboard & Heatsink (6)	Hard Drive (6)	Top Case (12)	Trackpad (2)
Backup Battery (2)	Speaker (1)	CD-ROM Drive Assembly (6)	Floppy Drive Assembly (10)
Microprocessor Daughterboard (2)	Feet (2)	Logic Board (7)	PCMICA Eject Mechanism (1)
Display Assembly (7)	Bezel (4)	Display (4)	Clutch Assembly (10)

# Screw Box